

Analog MP3 Watch User Manual

I. Key Definition



II. Specifications

Memory Unit:	Built-in 128MB / 256MB Flash
	Memory
Port:	4 Pin USB round port
Battery:	Built-in Hi Li-ion rechargeable
	150mAh/3.7V battery
Battery Life:	> 9 hours continuous playing
	time when fully charged
USB Transfer Rate:	USB 1.1 (Max. 5Mbps)
MP3 Compression	32Kbps to 256 Kbps
Rate:	
Output Frequency	20Hz to 20KHz
Rate:	
Earphone Output:	4MW + 4MW
Operating Platform:	Windows 98/Me/NT/2000/XP

III. Charging

- The built-in battery can be charged either by USB or by-A/C Transformer. When properly connected for charging, the red light will illuminate. The battery is fully charged the green light will illuminate.
- If red light flashes during playing mode, this indicates that the battery is low and the player will takes about 5 to 10 minutes to shut down automatically.

IV. Light Indication

- While charging the battery, the red light indicates a charge is in process. A green light indicates the charging process has been competed.
- During the transmission of files, the red light will flash.
 The red light will stop flashing when the transference of files is complete.
- Green light will flash during play mode.
 The Red light and Green light will alternate flashing while being connected to the computer or while MP3 is being shut down.

V. Operation Instruction

- 1. Start / Pause / Close
 - (1) To Start the MP3 player mode, the earphone must be connected. Press "PLAY" button for 2 seconds to start the player. The green light will blink slowly to show activation of the software.
 - (2) In playing mode; press "PLAY" once to pause, and again to resume play.
 - (3) In case music playing is paused for more than 10 minutes, the MP3 player will shut down automatically.

2. Stop / Turn off

Press "PLAY" and hold to stop playing and turn off power supply at the same time. Disconnecting ear phone will shut down MP3 playing mode.

3. Track selection

- When playing music, press "FF/VOL+" to jump to the next track; press "REW/VOL-" to back to the previous track
- When playing music, press and hold "REW/VOL-" to increase music volume; press and hold "FF/VOL+" to decrease music volume.

5. EQ (Equalizer) Mode

You can select 5 EQ musical modes; Normal, Pop, Classic, Rock and Jazz. Press "EQ" to select the mode of your choice.

6. Memory function

If the player is closed properly, it will save the playing conditions including volume, EQ mode and the track being played immediately before the closure. When it is opened again, it will extract the memory and play the track with the playing conditions like volume and EQ mode the same as those immediately before the closure.

VI. Driver Installation

- No driver installation is needed if the operating system is Windows ME / NT / 2000 or above or Mac OS8.6 or above.
- 2. Driver installation on Win 98 SE interface
 - (1) Connect the MP3 watch with the computer through its USB port, the PC will indicate that a new hardware device is found.
 - (2) Complete the driver installation as directed by the PC.
 - (3) When the installation is complete, double click "My Computer" and you will find a "Removable Disk" icon.

VII. Computer Connection

- 1. When properly connected, you can find the "Removable Disk" icon in "My Computer"
- 2. Download MP3 files to the nTren watch.
 - (1) Support musical files of MPEG 1/2, Layer 3, compression rate: 32kbps to 256kbps. Will not support shareware MP3 files.
 - (2) Red light blinks when downloading files. Blinking stops and red light on when it is completed.
 - (3) Do not disconnect the USB cable from either side while reading or transmitting files. Otherwise, the files may become corrupt or deleted.
- 3. MP3 watch can also be used as flash memory disk.
 - (1) Connect to the computer via USB cable and drag and drop files of any type.